



## **Safety Guidelines for WALL ANCHORING**

We all want our homes to be a safe place. But in our homes, accidents can put children at risk. By working together, we can help prevent these accidents and make the home a safer place.

The best way to help prevent furniture tip over accidents is to secure furniture to the wall. Idiya urges customers to inspect their chests of drawers and dressers to ensure that they are securely anchored to the wall using the restraints provided in the packaging.


### **prevent furniture tip-over accidents**

- Secure it! Furniture must be securely attached to the wall. Use the tip-over restraint provided with the product and the right hardware for your wall type. Consult our wall anchoring guide for help.
- Never put a TV or other heavy objects on top of a chest of drawers or any furniture not intended for use with a TV.
- Place heavy objects in the lowest drawers.
- Never let children climb or hang on drawers, doors or shelves.

### **Secure it! Wall anchoring guide**

#### **Furniture must be securely attached to the wall.**

The hardware used to secure your furniture to the wall depends on your wall material. If your wall material is not listed or if you have any questions, consult with a local hardware retailer.






*Figure 1*

**Wall material:**

Drywall or plaster with available wood stud

**Anchoring device:**

Screw inserted directly into stud. For example, a 5 mm wood screw provided with IKEA FIXA plug and screw set (Figure 1)




*Figure 2*

**Wall material:**

Drywall without available wood stud

**Anchoring device:**

Plug with screw. For example, an 8 mm plug provided with IKEA FIXA plug and screw set (Figure 2)



*Figure 3A and Figure 3B*

**Wall material:**

Masonry

**Anchoring device:**

Solid Wall: Plug with screw. For example, an 8 mm plug provided with IKEA FIXA plug and screw set (Figure 3A)

## WALL ANCHORING GUIDE

**IF YOUR WALL MATERIAL IS NOT LISTED OR IF YOU HAVE QUESTIONS, CONSULT WITH A LOCAL HARDWARE RETAILER.**

**WALL MATERIAL**

Drywall or plaster with available wood stud

**ANCHORING DEVICE**

Screw inserted directly into stud. For example, a 5 mm wood screw provided with IKEA FIXA plug and screw set (Figure 1)



FIGURE 1

**WALL MATERIAL**

Drywall without available wood stud

**ANCHORING DEVICE**

Plug with screw. For example, an 8 mm plug provided with IKEA FIXA plug and screw set (Figure 2)



FIGURE 2

**WALL MATERIAL**

Masonry

**ANCHORING DEVICE**

Solid Wall: Plug with screw. For example, an 8 mm plug provided with IKEA FIXA plug and screw set (Figure 3A)




FIGURE 3A

Hollow Wall: Toggle-style

(Figure 3B)




FIGURE 3B